



4+



This package includes;

- 1 Pet
- 2 AAA batteries


**Please Note**

- Please retain these instructions as they contain important information.
- Read all of the instructions before operating your pet.
- Adult supervision is required to change the batteries.
- This pet includes a tilt sensor and may operate differently than other Zhu Zhu Pets®.
- The Zhu Zhu™ Pony is a toy. It is not intended for use with live animals.
- Zhu Zhu™ Ponies come in many different colors and styles and may differ from the pet shown on this instruction sheet.


**CAUTION To prevent entanglement, keep hair away from wheels.**

**IMPORTANT! ADULT SUPERVISION AND ASSISTANCE MAY BE REQUIRED ON ASSEMBLY**

For more information on the Zhu Zhu™ Ponies and pet play sets and accessories please go to: [www.zhuzhupets.com](http://www.zhuzhupets.com)



Sets sold separately



**Unpacking your pet**


Remove all contents from package and discard any rubber bands, wire ties or other packaging materials that are not part of the product.

**Preparing your pet for operation**

The pet is ready to go as soon as it is removed from the package.

**Activation Buttons**

The pet has an activation button on its back, 1 and a chest button, 2. The Back Button activates Talk and Explore modes. The button on the chest acts as a bump sensor in Explore mode and as the Try Me button when pet is in Sleep mode. In Talk mode, the chest button makes your pet immediately play a Talk sound. The tilt sensor tells the pet when it is in an upright position allowing the motor to engage.



To disengage the motor either press the back button to make pet go to Sleep or tip the pet over to put it into Talk mode.

**Operating Modes**

The Pet has three Modes of operation, Talk Mode, Explore Mode and Sleep Mode.

**BATTERY INFORMATION**

- If the pet does not run or make sounds the batteries may be depleted. Replace with fresh AAA batteries. For best performance and battery life use Alkaline or better.
- Your pet works best on smooth, hard, even surfaces. It will not work on carpet or other soft surfaces.
- Running time and battery life will depend on play conditions and may vary.
- Do not let the pet run in sand or water. This may damage the electronics and gears.
- To make your pet go to sleep, press the back button while in explore mode.
- Spot clean only, do not soak.
- Remove the batteries if the pet is stored for long periods of time.
- If the pet get wet for any reason, remove the batteries and allow the pet to air dry overnight before attempting to operate it again.
- Batteries supplied with this toy are for in-store demonstration purposes and may require replacing in a short period of time.
- The pet is not designed to be a sleep toy, remove the batteries if your child wishes to take it to bed.


- Always replace used batteries with fresh Alkaline batteries. Only batteries of the same or equivalent type as recommended are to be used.
  - Batteries are to be inserted with the correct polarity.
  - Do not mix old batteries with new, do not mix Alkaline with standard carbon zinc or rechargeable nickel cadmium batteries.
  - Non-rechargeable batteries are not to be recharged.
  - Rechargeable batteries are to be removed from the toy before being charged.
  - Rechargeable batteries are only to be charged under adult supervision.
  - Exhausted batteries are to be removed from the toy.
  - Do not dispose of batteries in fire.
  - The supply terminals are not to be short-circuited.
- Claim:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Caution:** changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

- 1. Talk Mode:** this is the nurturing, loving mode when you want to give your pet special attention without having it try to gallop away from you. Press the Back Button 1 time from Sleep to make your pony talk. It will continue to make new sounds every few seconds or every time you push the Chest Tag button. After about one minute the pet will automatically go to sleep.
- 2. Explore Mode;** this is where you get to watch the pet go out and explore the world! In Talk Mode, press the Back Button again to engage the motor and put pet into Explore mode. In Explore Mode the pet will entertain you with crazy fun sounds and wacky movements. It will back up when it bumps its chest button. If the pet is tipped over while Exploring, the tilt sensor will automatically disengage the motor and put the pet into Talk Mode. To make it go again, turn the pet upright and push the back button. If left alone in explore mode the pet will automatically go to sleep after about three minutes.
- 3. Sleep Mode:** the pet will sleep to conserve energy and save the batteries when not in use. You can wake it up by pressing the Back Button. The tilt sensor has no effect in Sleep Mode, but it will prevent the pet from going into Explore when the back button is pushed while the pet is upside down. Sleep Mode also doubles as a Try-Me Mode for the pet. In Sleep mode the chest button is active and will cause the pet to make simple sounds each time it is pressed. It will then go back to sleep.

**Changing the Batteries**

Adult supervision is required.

- Open the flap on the back side of the pony and unscrew the battery box cover.
- Replace the two AAA batteries matching the polarity shown inside the battery compartment.
- Replace the battery cover and screw snug.



**Troubleshooting and operating tips**


- The pets are designed to act randomly and unpredictably. Yours may not act the same each time.
- **Keep fingers, hair, and loose clothing away from the wheels.**
- If hair gets caught around a wheel, stop the motor quickly by pressing the back button or simply turn the pet upside down, triggering the tilt sensor. Once stopped, slowly unwind hair from axle by turning the wheel by hand.

[www.ZhuZhuPets.com](http://www.ZhuZhuPets.com)

For Questions and Comments please call: 1 800 225 9319



©2012 Cepia LLC. 121 Hunter Ave. St. Louis Missouri 63124 Made in China



Complies with Toy Safety Standard ASTM F963

Please Recycle

**WARNING:**

All rubber bands and wire ties, as well as tags, are not parts of this toy and should be discarded for your child's safety. Colors and contents may vary from those shown on the package.

Printed in China

U.S. and Foreign patents pending;